ENGINEERED PERFORMANCE STANDARDS

BOOK NUMBER - 14

WHARFBUILDING



TABLE OF CONTENTS

BOOK 14

CHAPTER	DESCR	<u>IPTION</u>			PAGE
010	FENDER/DOLPHIN PILES:	Remove	w/	Floating Crane	1
020	FENDER PILES:	Remove	w/	Mobile Crane	3
030	FENDER/DOLPHIN PILES:	Drive new piles	w/	Floating Crane	5
040	FENDER PILES:	Drive new piles	w/	Mobile Crane	6
050	CHOCK BLOCKS:	Remove, Install	w/	Floating Crane	7
060	CHOCK BLOCKS:	Remove, Install	w/	Mobile Crane	8
070	WALES:	Remove, Install	w/	Floating Crane	9
080	WALES:	Remove, Install	w/	Mobile Crane	10
090	METAL CAPS:	Install, Replace	e on Fe	nder/Dolphin Piles	11
100	HEAVY TIMBER CONSTRUC	TION: Spiked, Op	en & Cl	ose Access Holes	12
110	WOOD CAMEL:	Repair, Replace			14

EPS SUPPLEMENTAL DATA CRAFT DELAY ALLOWANCE, JOB PREPARATION

CRAFT	JOB PREP	CRAFT DELAY SINGLE	
BOILER WORK	.4	23	33
CARPENTRY - GENERAL	.3	15	20
CARPENTRY - ROOFING	.6	20	25
COOLING/VENT/REFER.	.3	15	18
ELECTRICAL & ELECTRONIC	.3	16	20
HAZARDOUS WORK (ADD TO JP)	.2		
HEATING	.3	17	21
JANITORIAL	.3	11	13
MACHINE SHOP	.3	23	24
MACHINE REPAIR	.4	28	36
MASONRY - GENERAL - W/ PURCH. CONC.	.4	15 19	20 22
MOVING AND RIGGING	.3	28	40
PAINT - GENERAL - SPRAY	.2	16 17	17 19
PEST CONTROL	.3	14	17
PIPEFITTING - INTERIOR - EXTERIOR	.3	15 18	20 25
PLUMBING - INTERIOR - EXTERIOR	.3	17 15	20 20
ROADS & GRNDS - GENERAL - LABORERS	.3	16 15	20 20
SHEETMETAL	.3	15	20
STRUC IRON & WELD - FIELD - SHOP	.3	17 17	20 22
TRACKAGE	. 4		22
WHARFBUILDING	.5	24	32

FENDER/DOLPHIN PILES: Remove with a Floating Crane. : Task includes: securing the pile, bolt removal, and asiding the : pile to the barge or pier. The distance between locations is : defined as one move of 48 ft. A distance between work areas of : of 96 ft. equates to two additional locations, (96/48=2), or a : total of three locations. 144 ft. between locations equates to : three additional locations, (four total), etc.

TASK TIME STANDARDS LISTING

zT	001	(remove)	PILE-broken	ABOVE	water	line	includes remove
							cement from bolt hole.
zT	005	(remove)	PILE-broken	ABOVE	water	line	includes no cement
							removal from bolt hole.
zT	002	(remove)	PILE-broken	BELOW	water	line	includes remove
							cement from bolt hole.
zT	800	(remove)	PILE-broken	BELOW	water	line	includes no cememt
							removal from bolt hole.

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 001 Remove broken fender/dolphin piles w/ floating crane; piles are broken above the water line; task time includes securing the pile, cement and bolt removal, and asiding the pile to the barge.

000.58900 hours per pilings to remove

000.60000 hours per additional moves with the floating crane

ZT 005 Remove broken fender/dolphin piles with a floating crane; piles broken above the water line; task time includes securing the pile; removing the bolt (no cement removal); and asiding the pile to the barge.

000.46900 hours per pilings to remove

000.60000 hours per additional moves with the floating crane

ZT 002 Remove broken fender/dolphin piles w/ floating crane; piles are broken below the water line; task time includes securing the pile, cement and bolt removal, and asiding the pile to the barge.

000.52400 hours per pilings to remove

ZT 008 Remove broken fender/dolphin piles with a floating crane; piles broken below the water line; task time includes securing piles, removing the bolt (no cement removal), and asiding the pile to the barge.

000.40400 hours per pilings to remove

000.60000 hours per additional moves with the floating crane

2

Mobile Crane

FENDER PILES: Remove with Mobile Crane : Task includes: securing the pile, bolt removal, and asiding the : pile to the pier. The distance between locations is defined as : one move of 30 ft. A distance between work areas of 60 ft. will : equate to two additional locations, (60/30=2), for a total of : three locations. 90 ft. between locations is three additional : locations, (four total), etc.

TASK TIME STANDARDS LISTING

Z	T (003	(remove)	PILE-broken	ABOVE	water	line	includes remove
								cement from bolt hole.
\mathbf{z}	T (006	(remove)	PILE-broken	ABOVE	water	line	includes NO cement
								removal from bolt hole.
\mathbf{z}	T (004	(remove)	PILE-broken	BELOW	water	line	includes remove
								cement from bolt hole.
Z	T (007	(remove)	PILE-broken	BELOW	water	line	includes NO cement
								removal from bolt hole.

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 003

Remove broken fender piles w/ mobile crane; piles broken above the water line; task time includes securing the pile, cement an bolt removal, and asiding the pile to the pier.

000.58900 hours per pilings to remove

000.08600 hours per additional moves with the mobile crane

ZT 006 Remove broken fender piles with a mobile crane; piles broken above the water line; task time includes securing the pile, removing the bolt (no cement removal); and asiding the pile to the pier.

000.46900 hours per pilings to remove

000.08600 hours per additional moves with the mobile crane

ZT 004 Remove broken fender piles with a mobile crane; piles broken below the water line; task includes securing the pile, cement and bolt removal, and asiding the pile to the pier.

000.52400 hours per pilings to remove

ZT 007 Remove broken fender piles with a mobile crane; pile broken below the water line; task time includes securing the pile, removing the bolt (no cement removal); and asiding the pile to the pier.

000.40400 hours per pilings to remove

FENDE/DOLPHIN PILES: Drive new piles with a Floating Crane.

Notes: Drive piles with a single or double hoist.

For fender piles at various locations; task time includes

timber preparation, inspection, installation and asiding pile

parts. The distance between locations is defined as one move of

48 ft. A distance between work areas of 96 ft. equates to two

additional locations (96/48=2), or a total of three locations;

144 ft. between work area will be three additional locations, or

a total of four locations, etc.

TASK TIME STANDARDS LISTING

ZT 009 PILE (Drive) new piles with a DOUBLE hoisted FLOATING CRANE.

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 009 Install new wooden fender/dolphin piles using a floating crane (two-hoisted pile driver), task time includes timber preparatio inspection, installation, and asiding excess pile parts.

001.14200 hours per pilings to drive in

: FENDER PILES: Drive new piles with a Mobile Crane.

: Notes: Drive piles with a single or double hoist crane.

: For fender piles at various locations; task time includes

: timber preparation, inspection, installation, and asiding pile

: parts. The distance between locations is defined as on move

: of 30 ft. A distance between work areas of 60 ft. would equate

: to two additional locations (60/30=2) or a total of three

: locations; 90 ft. equates to three aditional locations, or a

: total of four loactions, etc.

TASK TIME STANDARDS LISTING

ZT 011 PILE: (Drive) new pile with a SINGLE hoisted MOBILE CRANE. ZT 010 PILE: (Drive) new pile with a DOUBLE hoisted MOBILE CRANE.

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 011 Install new wooden fender piles using a mobile crane with a single-hoisted pile driver; task time includes timber preparation, inspection, installation and asiding excess pile parts.

001.49600 hours per pilings to drive in

000.08600 hours per additional moves with the mobile crane

ZT 010 Install new wooden fender piles using a mobile crane with a two-hoisted pile driver; task includes timber preparation, inspection, installation, and asiding excess pile parts.

001.14200 hours per pilings to drive in

PAGE

Remove, Install w/ Floating Crane

: CHOCK BLOCKS: Remove, Install with a Floating Crane
: Notes: For chock blocks at various locations; For removing chock
: blocks task times includes bolt removal, prying loose the chock
: blocks and asiding the chock blocks to the barge. Installing
: the chock block includes all measuring and drilling operations
: hoisting and installation of the new chock. Distances between
: locations is defined as one move of 48 ft. A distance between
: work areas of 96 ft., equates to two additional locations
: (96/48=2) or a total of three locations; 144 ft. between work
: locations equates to three additional locations, or a total of
: four locations, etc.

TASK TIME STANDARDS LISTING

ZT 012 (remove) CHOCK BLOCKS- includes remove cement from bolt ZT 013 (remove) CHOCK BLOCKS- includes NO cement removal from bolt hole ZT 020 (fabricate & install) CHOCK BLOCKS-

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 012 Remove chocks from fenders using a floating crane, task time includes removal of cement and bolts, prying loose the chock block, and asiding the chock block to the barge.

000.56300 hours per chock blocks to remove

000.60000 hours per additional moves with the floating crane

ZT 013 Remove chocks from fenders using a floating crane; task time includes bolt removal (no cement removal required), prying loose the chock blocks, and asiding the chock blocks to the barge.

000.34400 hours per chock blocks to remove

000.60000 hours per additional moves with the floating crane

ZT 020 Fabricate and install chock blocks on a fender system using a floating crane, task time includes all measuring, drilling and cutting operations.

000.60900 hours per chock blocks to install

Remove, Install w/ Mobile Crane

: CHOCK BLOCKS: Remove, Install with a Mobile Crane.

Notes: For chock blocks at various locations; Removing chock blocks task time includes removal of bolts, prying loose the chock blocks, and asiding the chock blocks to the pier.

Installing chock blocks includes all measuring and drilling operations, hoisting and installations of the new chocks. The distance between locations is defined as one move of 48 ft. A distance between work areas of 96 ft. equates to two additional locations (96/48=2), or a total of three locations; 144 ft. between locations will be three additional locations, or a total of four locations, etc.

TASK TIME STANDARDS LISTING

ZT 014 (remove) CHOCK BLOCKS- includes remove cement from bolt hole ZT 015 (remove) CHOCK BLOCKS- includes no cement removal from bolt hole ZT 021 (fabricate & install) CHOCK BLOCKS-

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 014 Remove chocks from fenders using a mobile crane; task time includes the removal of cement and bolts, prying loose the choc blocks, and asiding the chock blocks to the pier.

000.56300 hours per chock blocks to remove

000.08600 hours per additional moves with the mobile crane

ZT 015 Remove chock blocks from fenders using a mobile crane; task time includes bolt removal (no cement removal required), prying loos chock blocks, and asiding the chock blocks to the pier.

000.33400 hours per chock blocks to remove

000.08600 hours per additional moves with the mobile crane

ZT 021 Fabricate and install chock blocks on a fender system using a mobile crane, task time includes all measuring, drilling, and cutting operations.

000.60900 hours per chock blocks to install

Remove, Install w/ Floating Crane

WALES: Remove, Install with a Floating Crane
Notes: For wales at various locations. Removing wales task time
includes prying loose the wale and asiding the wale to the
barge. Installing wales includes all measuring and drilling
operations, hoisting and installation of the new wales. The
distance between locations is defined one move of 48 ft. A
distance between work areas of 96 ft. equates to two additional
locations (96/48=2), or a total of three locations; 144 ft.
between locations will be three additional locations, or a total
of four locations, etc.

TASK TIME STANDARDS LISTING

ZT 016 (remove) WALES with a Floating Crane. ZT 017 (install) WALES with a Floating Crane.

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 016 Remove wales from pier using a floating crane, task time includes prying loose the wale and asiding to the barge.

000.40400 hours per wales to remove

000.60000 hours per additional moves with the floating crane

ZT 017 Install wales using a floating crane; task time includes all measuring and drilling operations, hoisting and installatio of the new wales.

000.43600 hours per wales to remove

PAGE

10

: WALES: Remove, Install with a Mobile Crane. : For wales at various locations; removal includes prying loose

: the wales and asiding the wales to the pier; installation : includes all measuring and drilling operations, hoisting, and

: installation of all new wales. the distance between locations is : defined as one move of 30 ft. A distance between work areas of : 60 ft. equates to two additional locations, (60/30=2), or a

: of three locations. 90 ft. between locations will be three : additional locations, or four total, etc.

TASK TIME STANDARDS LISTING

ZT 018 (remove) WALES with a Mobile crane. ZT 019 (install) WALES with a Mobile crane.

BOOK NUMBER 14

WALES:

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 018 Remove wales from piers using a mobile crane; task time includes prying loose the wale and asiding the wale to the pier

000.40400 hours per wales to remove

000.08600 hours per additional moves with the mobile crane

ZT 019 Install wales using a mobile crane; task time includes all measuring and drilling operations, hoisting and installation of new wales.

000.34600 hours per wales to install

METAL CAPS: Install, Replace on Fender/I

METAL CAPS; Install, Replace on Fender or Dolphin Piles.tall on Notes: Task times include the time required to walk between piles when replacing caps on fender piles. The task time for dolphin piles provides time for replacing caps at a single dolphin. No time is included for movement between dolphins.

TASK TIME STANDARDS LISTING

zT	022	ROOFING	PAPER	&	METAL	CAPS	(install)on	Fender	piles.
zT	024	ROOFING	PAPER	&	METAL	CAPS	(install)on	Dolphin	piles.
zT	023	ROOFING	PAPER	&	METAL	CAPS	(replace)on	Fender	piles.
$\mathbf{z}\mathbf{r}$	025	ROOFING	PAPER	æ	METAL	CAPS	(replace)on	Dolphin	piles.

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 023 Replace damaged roofing paper and metal caps on fender piles.
000.04200 hours per JOB SETUP TIME
000.22093 hours per fender piles

ZT 025 Replace damaged roofing paper and metal caps on dolphin piles.
000.04350 hours per JOB SETUP TIME
000.20193 hours per dolphin piles

HEAVY TIMBER CONSTRUCTION: Spiked, Open and Close Access Holes.

Notes:Open and close access holes in decking, piers, and wharfs constructed of 4" x 12" timbers. Time is allowed for cutting of timbers with a power saw, pulling spikes, reusing timbers, and driving spikes with an air hammer. Where covered with a bituminous slab, time has been allowed for removal and resurfacing of a 3" slab.

TASK TIME STANDARDS LISTING

zT	026	(open	&	close)	ACCESS	HOLE	4ft	x4ft	hole,	no	bituminous	slab
zT	027	(open	&	close)	ACCESS	HOLE	4ft	x8ft	hole,	no	bituminous	${\tt slab}$
zT	028	(open	&	close)	ACCESS	HOLE	5£t	x16ft	hole,	no	bituminous	slab
zT	029	(open	&	close)	ACCESS	HOLE	4ft	x4ft	hole,	3"	bituminous	slab
zT	030	(open	&	close)	ACCESS	HOLE	4ft	x8ft	hole,	3"	bituminous	slab
zT	031	(open	&	close)	ACCESS	HOLE	5ft	x16ft	hole,	3"	bituminous	slab

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 026 Decking, piers and wharves, 4" x 12" timbers; open and close 4'x4' holes for work access. Reuse timbers.

000.72400 hours per access holes

ZT 027 Decking, piers, and wharves, 4" x 12" timbers; open and close 4ft'x8ft holes for work access. Reuse timbers.

001.02300 hours per access holes

ZT 028 Decking, piers, and wharves, 4" x 12" timbers; open and close 5ft x16ft holes for work access. Reuse timbers.

002.07600 hours per access holes

ZT 029 Decking, piers, and wharves, 4" x 12" timbers with 3" bituminous slab cover; open and close 4ft x 4ft holes for work access.

Reuse timbers.

001.34560 hours per access holes

ZT 030 Decking, piers, and wharves, 4"x12" timbers with 3" bituminous slab cover; open and close 4ft x8ft holes for work access.

Reuse timbers.

002.36620 hours per access holes

ZT 031 Decking, piers, and wharves, 4"x12" timbers with 3" bituminous

13

ZT 031 Decking, piers, and wharves, 4"x12" timbers with 3" bituminous slab cover; open and close 5ft x16ft holes for work access. Reuse timbers.

004.68200 hours per access holes

BOOK NUMBER 14 CHAPTER NUMBER 110

WOOD CAMEL: Repair, Replace

:
WOOD CAMEL: Repair and Replace.
:

PAGE

14

TASK TIME STANDARDS LISTING

zT	032	WOOD	CAMEL FLOTATION	CELLS: (Replace)-including bottom decking
zT	033	WOOD	CAMEL FENDER:	(Repair) 20ft side fender timbers.
zT	034	WOOD	CAMEL FENDER:	(Repair) 8ft end fender timbers.
zT	035	WOOD	CAMEL:	(Repair) 20ft center timber.
zT	036	WOOD	CAMEL:	(Repair) 8ft end/center timber, includes
				fender replacement.
zT	037	WOOD	CAMEL:	(Remove)-rod for rethreading.
zT	038	WOOD	CAMEL:	(Repair)-internal cross beam.
zT	039	WOOD	CAMEL:	(Remove)-nut with acetylene torch.

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

ZT 032 Wood camel floatation cell repair.

015.66000 hours per cell to repair

ZT 033 Wood camel side fender repair; task time includes replace fenders, building support legs for new fenders.

005.53980 hours per side fenders to repair

ZT 034 Wood camel end fender repair; task time includes replace fenders and installation of new fenders.

001.91000 hours per Repair end fender

ZT 035 Wood camel 20ft center timber repair; task time includes replace fenders.

000.20900 hours per center timbers to repair

ZT 036 Wood camel end/center timber repair; task time includes replace timber.

009.42000 hours per end/center timber to repair

ZT 037 Wood camel threaded rod repair; task time includes complete removal of threaded rod.

001.91000 hours per threaded rod to repair

EPS TASK TIME STANDARDS - DESCRIPTIONS AND UNIT HOURS

15

ZT 038 Wood camel internal cross beam repair; task time includes removal and installation of cross beams.

000.71500 hours per occurrences

ZT 039 Wood camel, nut removal with acetylene torch; task time includes use of acetylene torch to remove frozen nuts from camel.

000.28900 hours per JOB SETUP TIME

000.01500 hours per nuts burned off

TASK TIME STANDARDS DEVELOPMENT BACKUP

- ZT 001 1 REMOVE SEALING CEMENT FROM BOLT HOLES WITH AIR CHI SEL FOR 1 PILE; 1 BOLT PER PILE (.011 + (1)(.109))
 - 2 MOVE BOOM TO BROKEN PILE, ATTACH TO AND REMOVE SLI NG FROM PILE; FOR EACH PILE
 - 3 BREAK NUT OFF BOLT WITH AIR DRIVER AND WRENCH FOR 1 PILE; 1 BOLT PER PILE (.081 + (1)(.054))N
 - 4 REMOVE BOLT FROM PILE WITH CRANE
 - 5 REMOVE AND ASIDE TOP PORTION OF PILE TO MATERIALS BARGE OR PIER FOR EACH PILE
 - 6 PULL BOTTOM PORTION OF PILE, RAISE AND ASIDE TO MA TERIALS BARGE OR PIER
 - 7 MOVE CRANE BETWEEN LOCATIONS; EACH MOVE IS 48FT
- ZT 002 1 REMOVE SEALING CEMENT FROM BOLT HOLES WITH AIR CHI SEL FOR 1 PILE; 1 BOLT HOLE PER PILE (.011 + (1)(.
 - 2 MOVE BOOM TO BROKEN PILE; ATTACH TO AND REMOVE SLING, FOR EACH PILE
 - 3 BREAK NUT OFF BOLT WITH AIR DRIVER AND WRENCH FOR EACH PILE; 1 BOLT PER PILE (.081 + (1)(.054))N
 - 4 REMOVE BOLT FROM PILE WITH CRANE FOR EACH PILE
 - 5 PULL FENDER OR DOLPHIN PILE; RAISE AND ASIDE TO MA TERIALS BARGE OR PIER
 - 6 MOVE CRANE BETWEEN LOCATINS, EACH MOVE = 48FT
- ZT 003 1 REMOVE SEALING CEMENT FROM BOLT HOLES WITH AIR CHI SEL FOR EACH PILE; 1 BOLT HOLE PER PILE (.011 + (1
 - 2 MOVE BOOM TO BROKEN PILE, ATTACH TO AND REMOVE SLI NG FOR EACH PILE
 - 3 BREAK OFF BOLT WITH AIR DRIVER AND WRENCH FOR EACH PILE; 1 BOLT PER PILE (.081 + (1)(.054))N
 - 4 REMOVE BOLT FROM PILE WITH CRANE
 - 5 REMOVE AND ASIDE TOP PORTION OF PILE TO PIER
 - 6 PULL BOTTOM PORTION OF PILE, RAISE AND ASIDE TO PI
 - 7 MOVE CRANE BETWEEN LOCATIONS, EACH MOVE IS 30FT
- ZT 004 1 REMOVE SEALING CEMENT FROM BOLT HOLES WITH AIR CHI SEL FOR EACH PILE; 1 BOLT HOLE PER PILE (.011 + (1
 - 2 MOVE BOOM TO BROKEN PILE, ATTACH TO AND REMOVE SLI NG
 - 3 BREAK OFF BOLT WITH AIR DRIVER AND WRENCH FOR EACH PILE; 1 BOLT PER PILE (.018 + (1)(.054))N
 - 4 REMOVE BOLT FROM PILE WITH CRANE
 - 5 PULL FENDER PILE, RAISE AND ASIDE TO PIER
 - 6 MOVE CRANE BETWEEN LOCATIONS, EACH MOVE IS 30FT
- ZT 005 1 MOVE BOOM TO BROKEN PILE, ATTACH TO AND REMOVE SLI NG FROM PILE FOR EACH PILE
 - 2 BREAK NUT OFF BOLT WITH AIR DRIVER AND WRENCH FOR EACH PILE; 1 BOLT PER PILE (.081 +(1)(.054))N
 - 3 REMOVE BOLT FROM PILE WITH CRANE
 - 4 REMOVE AND ASIDE TOP PORTION OF PILE TO MATERIALS BARGE OR PIER
 - 5 PULL BOTTOM PORTION OF PILE, RAISE AND ASIDE TO MA TERIALS BARGE OR PIER
 - 6 MOVE CRANE BETWEEN LOCATIONS; EACH MOVE IS 48FT

- ZT 006 1 MOVE BOOM TO BROKEN PILE, ATTACH TO AND REMOVE SLI NG FROM PILE
 - 2 BREAK NUT OFF BOLT WITH AIR DRIVER AND WRENCH FOR EACH PILE; 1 BOLT PER PILE ((.081) + (1)(.054))N
 - 3 REMOVE BOLT FROM PILE WITH CRANE
 - 4 REOVE AND ASIDE TOP PORTION OF PILE TO PIER
 - 5 PULL BOTTOM PORTION OF PILE, RAISE AND ASIDE TO PI
 - 6 MOVE MOBILE CRANE BETWEEN LOCATIONS; EACH MOVE IS 30FT
- ZT 007 1 MOVE BOOM TO BROKEN PILE, ATTACH TO AND REMOVE SLI NG FROM PILE
 - 2 BREAK NUT OFF BOLT WITH AIR DRIVER AND WRENCH FOR EACH PILE; 1 BOLT PER PILE (.081 + (1)(.054))N
 - 3 REMOVE BOLT FROM PILE WITH CRANE
 - 4 PULL FENDER PILE, RAISE AND ASIDE TO PIER
 - 5 MOVE MOBILE CRANE BEWTEEN LOCATIONS; EACH MOVE IS 30FT
- ZT 008 1 MOVE BOOM TO BROKEN PILE; ATTACH TO AND REMOVE SLI NG FROM PILE
 - 2 BREAK NUT OFF BOLT WITH AIR DRIVER FOR EACH PILE; 1 BOLT PER PILE (.081 + (1)(.054))N
 - 3 REMOVE BOLT FROM PILE WITH CRANE
 - 4 PULL FENDER OR DOLPHIN PILE, RAISE AND ASIDE TO BARGE OR PIER
 - 5 MOVE FLOATING CRANE BETWEEN LOCATIONS; EACH MOVE I S 48FT
- ZT 009 1 CUT OFF SMALL END OF PILE 2 CUTS PER PILE (.051 + (2)(.023))N
 - 2 CUT OFF LARGE END OF PILE (CHAIN SAW) TO RECEIVE H AMMER; 4 CUTS PER PILE (.051 + (4)(.023))N
 - 3 HOIST: SWING TO POSITION, LOWER PILE AND HAMMER, AND RETURN HOOK
 - 4 INSPECT PILES FOR PROPER POSITION AND DISPLACEMENT AND SECURE FOR DRIVING WITH MOORING ROPE USE WINC
 - 5 DRIVE ONE FENDER OR DOLPHIN PILE USING A STEAM OR DIESEL HAMMER
 - 6 DRILL 1-1/8" DIAMETER HOLE THROUGH EACH PILE WITH AIR DRILL; 1 HOLE FOR EACH PILE (.038 + (1)(.018))
 - 7 COUNTERBORE 4" X 4" DEEP HOLE IN EACH PILE, 1 HOLE FOR EACH PILE (.038 + (1)(.054))N
 - 8 SECURE PILE TO WALES WITH BOLTS USING AIR DRIVER A ND WRENCH
 - 9 CUT OFF EXCESS PILE WITH CHAIN SAW 1 CUT FOR EACH PILE (.051 + (1)(.023))N
 - 10 HOIST EXCESS PILE AND ASIDE TO BARGE OR PIER
 - 11 MOVE FLOATING CRANE BETWEEN LOCATIONS; EACH MOVE I S 48FT

- ZT 010 1 CUT OFF SMALL END OF PILE FOR EACH PILE; 2 CUTS PE R PILE (.051 + (2)(.023))N
 - 2 CUT OFF LARGE END OF PILE (CHAIN SAW) TO RECEIVE H AMMER FOR EACH PILE; 4 CUTS PER PILE (.051 + (4)(.
 - 3 HOIST: SWING TO POSITION, LOWER PILE AND HAMMER, AND RETURN HOOK
 - 4 INSPECT PILES FOR PROPER POSITION AND DISPLACEMENT AND SECURE FOR DRIVING WITH MOORING ROPE USE WINC
 - 5 DRIVE FENDER PILES USING A STEAM OR DIESEL HAMMER
 - 6 DRILL 1-1/8" DIAMETER HOLE THROUGH PILE WITH AIR D RILL; 1 HOLE FOR EACH PILE (.038 + (1)(.018))N
 - 7 COUNTERBORE 4" X 4" DEEP HOLE IN PILE, 1 HOLE FOR EACH PILE (.038 + (1)(.054))N
 - 8 SECURE PILE TO WALES WITH BOLTS USING AIR DRIVER A ND WRENCH
 - 9 CUT OFF EXCESS PILE WITH CHAIN SAW 1 CUT FOR EACH PILE (.051 + (1)(.023))N
 - 10 HOIST EXCESS PILE AND ASIDE TO PIER
 - 11 MOVE MOBILE CRANE BETWEEN LOCATIONS; EACH MOVE IS 30FT
- ZT 011 1 CUT OFF SMALL END OF PILE; 2 CUTS PER PILE (.051 + (2) (.023))N
 - 2 CUT OFF LARGE END OF PILE (CHAIN SAW) TO RECEIVE H AMMER; 4 CUTS PER PILE (.051 + (4)(.023))N
 - 3 HOIST: SWING TO POSITON, LOWER PILE AND RETURN HO
 - 4 INSPECT PILE FOR PROPER POSITION AND DISPLACEMENT AND SECURE FOR DRIVING WITH ROPE
 - 5 HOIST: SWING TO POSITION, LOWER HAMMER, AND RETURN HOOK
 - 6 DRIVE FENDER PILES USING A STEAM OR DIESEL HAMMER
 - 7 DRILL 1-1/8" DIAMETER HOLE THROUGH EACH PILE WITH AIR DRILL, 1 HOLE FOR EACH PILE (.038 + (1)(.018))
 - 8 COUNTERBORE 4" DIAMETER X 4" DEEP HOLE IN EACH PIL E; 1 HOLE FOR EACH PILE (.038 + (1)(.054))N
 - 9 SECURE PILE TO WALES WITH BOLTS USING AIR DRIVER A ND WRENCH
 - 10 CUT OFF EXCESS PILE WITH CHAIN SAW 1 CUT PER PILE (.051 + (1)(.023))N
 - 11 HOIST EXCESS PILE AND ASIDE TO PIER
 - 12 MOVE MOBILE CRANE BETWEEN LOCATIONS; EACH MOVE IS
- ZT 012 1 REMOVE SEALING CEMENT FROM BOLT HOLE WITH AIR CHIS EL. 2 HOLES PER CHOCK (.011 + (2)(.109))N
 - 2 BREAK NUT OFF BOLT WITH AIR DRIVER AND WRENCH 2 NU TS PER CHOCk (.018 + (2)(.054))N
 - 3 REMOVE BOLT FROM TIMBER WITH CRANE 2 BOLTS PER CHO
 - 4 SEPARATE CHOCK BLOCKS FROM WALE WITH PRYING IRON
 - 5 PULL, RAISE, AND LOWER ASIDE CHOCK BLOCKS USING CR ANE
 - 6 REMOVE BOLTS FROM CHOCK BLOCKS WITH CLAW HAMMER
 - 7 MOVE FLOATING CRANE BETWEEN LOCATIONS; EACH MOVE I S 48FT

- ZT 013 1 BREAK NUT OFF BOLT WITH AIR DRIVER AND WRENCH 2 NU TS PER CHOCK (.018 + (2)(.054))N
 - 2 REMOVE BOLT FROM TIMBER WITH CRANE 2 BOLTS PER CHO
 - 3 SEPARATE CHOCK BLOCKS FROM WALE WITH PRYING IRON
 - 4 PULL, RAISE, AND LOWER ASIDE CHOCK BLOCKS USING CR
 - 5 REMOVE BOLTS FROM CHOCK BLOCKS WITH CLAW HAMMER AN D ASIDE TO PARTS BIN
 - 6 MOVE FLOATING CRANE BETWEEN LOCATIONS; EACH MOVE I S 48FT
- ZT 014 1 REMOVE SEALING CEMENT FROM BOLT HOLE WITH AIR CHIS EL . 2 HOLES PER CHOCK. (.011 + (2)(.109))N
 - 2 BREAK NUT OFF BOLT WITH AIR DRIVER AND WRENCH 2 BO LTS PER CHOCK (.018 + (2)(.054))N
 - 3 REMOVE BOLT FROM TIMBER WITH CRANE 2 BOLTS PER CHO
 - 4 SEPARATE CHOCK BLOCKS FROM WALE WITH PRYING IRON
 - 5 PULL, RAISE, AND LOWER ASIDE CHOCK BLOCKS USING CR
 - 6 REMOVE BOLTS FROM CHOCK BLOCKS WITH CLAW HAMMER AS IDE TO PARTS BIN
 - 7 MOVE MOBILE CRANE BETWEEN LOCATIONS; EACH MOVE IS 30FT
- ZT 015 1 BREAK NUT OFF BOLT WITH AIR DRIVER AND WRENCH 2 NU TS PER CHOCK (.018 + (2)(.054))N
 - 2 REMOVE BOLT FROM TIMBER WITH CRANE 2 BOLTS PER CHO
 - 3 SEPARATE CHOCK BLOCKS FROM WALE WITH PRYING IRON I
 - 4 PULL, RAISE, AND LOWER ASIDE CHOCK BLOCKS USING CR ANE
 - 5 REMOVE BOLTS FROM CHOCK BLOCKS WITH CLAW HAMMER AN D ASIDE TO PARTS BIN
 - 6 MOVE MOBILE CRANE BETWEEN LOCATIONS, EACH MOVE IS 30FT
- ZT 016 1 REMOVE NUTS FROM ANCHORED TEE BOLT WITH REVERSIBLE AIR DRIVER; 4 BOLTS PER WALE (.010 + (4)(.040))N
 - 2 SEPARATE WALE FROM PIER USING PRYING IRON
 - 3 RAISE WALE AND LOWER ASIDE WITH CRANE, USING PRYIN G IRON TO ASSIST IN REMOVAL
 - 4 REMOVE FROM AND REINSTALL 4 BOLTS TO ANCHOR IN PIE R, SECURE WITH WOODEN WEDGE
 - 5 MOVE FLOATING CRANE BETWEEN LOCATIONS; EACH MOVE I S 48FT

- ZT 017 1 MEASURE CENTER DISTANCE OF TEE BOLT ANCHORS AND MA RK ON NEW WALE FOR DRILLING; 4 BOLT HOLES PER WALE
 - 2 HOIST WALE, MOVE TO POSITION, SET ON BOLTS, AND PU SH INTO PLACE WITH CRANE
 - 3 INSTALL 4 NUTS AND TIGHTEN WITH AIR DRIVER FOR EAC H WALE
 - 4 MOVE FLOATING CRANE BETWEEN LOCATIONS; EACH MOVE I S 48FT
- ZT 018 1 REMOVE NUTS FROM ANCHORED TEE BOLT WITH REVERSIBLE AIR DRIVER FOR WALE; 4 BOLTS PER WALE (.010 + (4)
 - 2 SEPARATE WALE FROM PIER USING PRYING IRON
 - 3 RAISE WALE AND LOWER ASIDE WITH CRANE, USING PRYIN G IRON TO ASSIST IN REMOVAL
 - 4 REMOVE AND REINSTALL 4 BOLTS TO ANCHOR IN PIER, SE CURE WITH WOODEN WEDGE, FOR EACH WALE
 - 5 MOVE MOBILE CRANE BETWEEN LOCATIONS; EACH MOVE IS 30FT
- ZT 019 1 MEASURE CENTER DISTANCES OF TEE BOLT ANCHORS AND M ARK ON NEW WALE FOR DRILLING; 4 BOLT HOLES PER WAL
 - 2 HOIST WALE, MOVE TO POSITION, SET ON BOLTS, AND PU SH INTO PLACE WITH CRANE
 - 3 INSTALL 4 NUTS AND TIGHTEN WITH AIR DRIVER FOR EACH WALE
 - 4 MOVE MOBILE CRANE BETWEEN LOCATIONS; EACH MOVE IS 30FT
- ZT 020 1 POSITION TIMBERS FOR SAWING AND DRILLING, USE CRAN
 - 2 MARK TIMBERS FOR ANGLE CUT USING ANGLE TEMPLATE
 - 3 SAW TWO ANGULAR CUTS INTO CHOCK BLOCK USING POWER CHAIN SAW
 - 4 TAPER PILES TO RECEIVE CHOCK BLOCKS USING TEMPLATE AND AXE
 - 5 SAW 2" X 4" BOARD, 2FT 4FT LENGTHS, TWO, FOR EAC H CHOCK BLOCK
 - 6 POSITION AND NAIL TWO 2" X 4" BOARDS TO TOP SIDE OF NEW CHOCK BLOCK
 - 7 NAIL FREE END OF TWO 2" X 4" BOARDS TO HOLD CHOCK IN POSITION FOR DRILLING
 - 8 WITH AIR TOOL; DRILL 1" DIAMETER HOLE THROUGH TIMB ER; TWO HOLES FOR EACH CHOCK (.038 + (2)(.018))N
 - 9 WITH AIR TOOL, COUNTERBORE 4" X 4" HOLE IN TIMBER; TWO HOLES IN EACH CHOCK BLOCK ((.038) + (2)(.054)
 - 10 HOIST CHOCK BLOCK, MOVE TO POSITION, AND PUSH INTO PLACE WITH CRANE
 - 11 SECURE CHOCK BLOCKS WITH TWO BOLTS EACH, USING AIR DRIVER AND WRENCH
 - 12 REMOVE TWO 2" X 4" BOARDS FROM CHOCK BLOCK AND WAL E, AND ASIDE FOR EACH CHOCK BLOCK
 - 13 MOVE FLOATING CRANE BETWEEN LOCATIONS; EACH MOVE I S 48FT

- ZT 021 1 POSITION TIMBERS FOR SAWING AND DRILLING, USE CRAN E
 - 2 MARK TIMBERS FOR ANGLE CUT USING ANGLE TEMPLATE
 - 3 SAW TWO ANGULAR CUTS INTO CHOCK BLOCK USING POWER CHAIN SAW
 - 4 TAPER PILES TO RECEIVE CHOCK BLOCKS USING TEMPLATE AND AXE
 - 5 SAW 2" X 4" BOARD, 2FT 4FT LENGTHS, TWO, FOR EAC H CHOCK BLOCK
 - 6 POSITION AND NAIL TWO 2" X 4" BOARDS TO TOP SIDE OF EACH NEW CHOCK BLOCK
 - 7 NAIL FREE END OF TWO 2" X 4" BOARDS TO HOLD CHOCK IN POSITION FOR DRILLING FOR CHOCK
 - 8 WITH AIR TOOL; DRILL 1" DIAMETER HOLE THROUGH TIMB ER; TWO HOLES FOR EACH CHOCK (.038 + (2)(.018))N
 - 9 WITH AIR TOOL, COUNTERBORE 4" X 4" HOLE IN TIMBER; TWO HOLES IN EACH CHOCK BLOCK (.038 + (2)(.054))N
 - 10 HOIST CHOCK BLOCKS, MOVE TO POSITION, PUSH INTO PL ACE WITH CRANE
 - 11 SECURE CHOCK BLOCKS WITH TWO BOLTS EACH, USING AIR DRIVER AND WRENCH
 - 12 REMOVE TWO 2" X 4" BOARDS FROM CHOCK BLOCK AND WAL E. AND ASIDE
 - 13 MOVE MOBILE CRANE BETWEEN LOCATIONS, EACH MOVE IS 30FT
- ZT 022 1 INSTALL ROOFING PAPER AND METAL CAPS ON FENDER PIL E .042 + N(.14293)
- ZT 023 1 REMOVE OLD ROOFING PAPER AND METAL CAP AND INSTALL NEW CAP ON FENDER PILE .042 + N(.22093)
- ZT 024 1 INSTALL ROOFING PAPER AND METAL CAP ON DOLPHIN PIL E .0435 + N(.14283)
- ZT 025 1 REMOVE OLD ROOFING PAPER AND METAL CAP AND INSTALL NEW CAP ON DOLPHIN PILES .0435 + N(.20193)
- ZT 026 1 MEASURE, MARK, AND POWER SAW 4" X 12" PLANKS, 8 CU
 TS FOR EACH 4FT X 4FT ACCESS HOLE (.044 + (8)(.011
 - 2 CHOP WITH ADZ TO EXPOSE SPIKE HEADS, 20 SPIKES FOR EACH ACCESS HOLE (.006 + 20(.011))N
 - 3 PULL SPIKE WITH CLAW BAR, 20 SPIKES FOR EACH ACCES S HOLE (.001 + 20(.003))N
 - 4 PRY TO LOOSEN AND PRY OFF PIECE OF LUMBER WITH BAR 4 PIECES FOR EACH ACCESS HOLE (.006 + (4)(.021))N
 - 5 HANDLE PLANKS TO STACK AND TO POSITION FOR INSTALL ING; 3 30 POUNDS; HANDLE 4 PIECES TWICE FOR EACH
 - 6 OBTAIN, SET AND DRIVE 8 3/16" X 8" SPIKES WITH A IR HAMMER; A TOTAL OF 24 SPIKES FOR EACH ACCESS HO

- ZT 027 1 MEASURE, MARK, AND POWER SAW 4" X 12" PLANKS, 8 CU
 TS FOR EACH 4FT X 4FT ACCESS HOLE (.044 + (8)(.011
 - 2 CHOP WITH ADZ TO EXPOSE SPIKE HEADS; 32 SPIKES FOR EACH ACCESS HOLE (.006 + (32)(.011))N
 - 3 PULL SPIKE WITH CLAW BAR; 32 SPIKES FOR EACH ACCES S HOLE (.001 + (32)(.003))N
 - 4 PRY TO LOOSEN AND PRY OFF PIECE OF LUMBER WITH BAR 6 PIECES FOR EACH ACCESS HOLE (.006 + (6)(.021))N
 - 5 HANDLE PLANKS TO STACK AND TO POSITION FOR INSTALL ING; 3-30 POUNDS; HANDLE 6 PIECES TWICE FOR EACH A
 - 6 OBTAIN, SET, AND DRIVE 8 3/16" X 8" SPIKES WITH AIR HAMMER; A TOTAL OF 32 SPIKES FOR EACH ACCESS H
- ZT 028 1 MEASURE, MARK, AND POWER SAW, 4" X 12" PLANKS; 10
 CUTS FOR EACH ACCESS HOLE (.044 + (10)(.011))N
 - 2 CHOP WITH ADZ TO EXPOSE SPIKE HEADS; 60 SPIKES FOR EACH ACCESS HOLE (.006 + (60)(.011))N
 - 3 PULL SPIKE WITH CLAW BAR; 60 SPIKES FOR EACH ACCES S HOLE (.001 + (60)(.003))N
 - 4 PRY TO LOOSEN AND PRY OFF PIECE OF LUMBER WITH BAR 13 PIECES FOR EACH ACCESS HOLE (.006 + (13)(.021)
 - 5 HANDLING PLANKS TO STACK AND TO POSITION FOR INSTA LLING; 3 - 30 POUNDS; HANDLE 9 PIECES TWICE EACH A
 - 6 HANDLE PLANKS TO STACK AND TO POSITION FOR INSTALL ING; 2 MEN; 4 PLANKS TWICE FOR EACH ACCESS HOLE (
 - 7 OBTAIN, SET, AND DRIVE 8 3/16" X 8" SPIKES WITH AIR HAMMER; A TOTAL OF 64 SPIKES FOR EACH ACCESS H
- ZT 029 1 BREAK UP, LOOSEN, AND LOAD ON TRUCK 1 SQ. YARD OF 3" BITUMINOUS SLAB; 3 SQUARE YARD FOR EACH ACCESS
 - 2 DECKING, PIERS, AND WHARFS, 4" X 12" TIMBERS; OPEN AND CLOSE 4FT X 4FT HOLES FOR WORK ACCESS; RE-USE
 - 3 RESURFACE WITH BITUMINOUS SLAB FOR EACH ACCESS HOL E; NUMBER OF LAYERS = 1; NUMBER OF SQUARE YARDS =
- ZT 030 1 BREAK UP, LOOSEN AND LOAD ON TRUCK 1 SQUARE YARD 3
 " BITUMINOUS SLAB; 7 SQUARE YARDS FOR EACH ACCESS
 - 2 DECKING, PIERS, AND WHARFS, 4" X 12" TIMBERS; OPEN AND CLOSE 4FT X 8FT HOLES FOR WORK ACCESS; RE-USE
 - 3 RESURFACE WITH BITUMINOUS SLAB FOR EACH ACCESS HOL E; NUMBER OF LAYERS = 1; NUMBER OF SQUARE YARDS =
- ZT 031 1 BREAK UP, LOOSEN, AND LOAD ON TRUCK 1 SQUARE YARD OF 3" THICK BITUMINOUS SLAB; 14 SQUARE YARDS FOR E
 - 2 DECKING, PIERS, AND WHARFS, 4" X 12" TIMBERS; OPEN AND CLOSE 5FT X 16FT HOLES FOR WORK ACCESS; RE-US
 - 3 RESURFACE WITH BITUMINOUS SLAB FOR EACH ACCESS HOL E; NUMBER OF LAYERS = 1; NUMBER OF SQUARE YARDS =

- ZT 032 1 REMOVE FLOTATION MATERIAL FROM CAMEL
 - 2 REMOVE BOTTOM DECKING FROM CAMEL
 - 3 INSTALL FLOTATION MATERIAL
 - 4 INSTALL BOTTOM DECKING TO FLOTATION CELL
- ZT 033 1 REMOVE 20 FT. SIDE FENDER TIMBER FROM CAMEL
 - 2 INSTALL NEW 20 FT. SIDE FENDER TO CAMEL
 - 3 BUILD FOUR SUPPORT LEGS FOR 20 FT. FENDER TIMBER
 - 4 REMOVE AND DISASSEMBLE LEGS FROM SIDE FENDER TIMBE R (4 LEGS SUPPORTING 1 FENDER TIMBER)
- ZT 034 1 REMOVE 8 FT. END FENDER TIMBER FROM CAMEL
 - 2 INSTALL NEW 8 FT. END FENDER ON CAMEL
- ZT 035 1 REMOVE 20 FT. CEMTER TIMBER FROM CAMEL
 - 2 INSTALL NEW 20 FT. CENTER TIMBER
- ZT 036 1 REMOVE 8 FT. END OR CENTER TIMBER FROM CAMEL
 - 2 INSTALL NEW 8 FT. END OR CENTER TIMBER
- ZT 037 1 REMOVE 9FT 6" X 1 3/4" THREADED ROD FROM CENTER TIMBER
- ZT 038 1 REMOVE INTERNAL CROSS BEAMS FROM CAMEL
 - 2 INSTALL NEW INTERNAL CROSS BEAM TIMBER
- ZT 039 1 BURN NUTS FROM PLANKING ROD .289 + N7(.015)
- ZT 040 1 REMOVE SEALING CEMENT FROM BOLT HOLES WITH AIR CHI SEL FOR EACH PILES; 1 BOLT PER PILE
 - 2 MOVE BOOM TO BROKEN PILE, ATTACH TO AND REMOVE SLI NG FROM PILE
 - 3 BREAK NUT OFF BOLT WITH AIR DRIVER AND WRENCH FOR EACH PILES, 1 BOLT PER PILE
 - 4 REMOVE BOLT FROM PILE WITH CRANE
 - 5 REMOVE AND ASIDE TOP PORTION OF PILE TO MATERIALS BARGE OR PIER
 - 6 PULL BOTTOM PORTION OF PILE, RAISE AND ASIDE TO MA TERIALS BARGE OR PIER
 - 7 MOVE CRANE BETWEEN LOCATIONS; EACH MOVE IS 48 FEET
 - 8 SLING AND UNSLING PILE WIRE SLING
 - 9 SLING AND UNSLING PILE MANILA SLING
 - 10 PULL TO BREAK OFF, RAISE AND ASIDE LOWER HALF OF P
 - 11 HOIST AND ASIDE UPPER HALF OF PILE
 - 12 HOIST NEW PILE THROUGH DECK OPENING AND POSITION F
 OR DRIVING
 - 13 DRIVE BEARING PILE
 - 14 ATTACH AND REMOVE SIDE DRIVING BLOCK
 - 15 INSTALL DRIVING COLLAR
 - 16 REMOVE DRIVING COLLAR
 - 17 INSTALL FOLLOWER AND REMOVE
 - 18 CUT PILE OFF EVEN WITH CAP
 - 19 HOIST EXCESS PILE END AND LOWER ASIDE
 - 20 DRILL HOLE THROUGH PILE OR CAP
 - 21 POSITION PLATE TO PILE
 - 22 INSTALL LARGE BOLTS
 - 23 INSTALL LARGE NUT
 - 24 PULL PILE UNDER CAP
 - 25 APPLY PRESERVATIVE TO CUT END AND BOLT HOLES